


Package contents (parts are not to scale):



Part	Description	Quantity
A	Fabric shade	1
B	Recharging Lamp body	1
C	USB-Type-C cable(100cm)	1


Care and Cleaning

EXTERIOR MAINTENANCE

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

Recharging Table Lamp

Art Nr. 11000000318&11000000118



Pre-Installation

PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED



Knife

Product detail information:

Max Watt: DC 5V 1A LED 5W

Kelvin: 3000K

Lumen: 300Lumen

Battery type: 4000mAh

Charging time: 3-4 hours

Running time: 6-8 hours

Lamp guarantee: 2 year



With 1Meter USB-Type C cable

Short touch (ON-20%-50%-100%-OFF)

Long touch for stepless dimming 10%-100%)

Switch instruction:

Please charge the lamp before use. The indicator light is Red when charging, and turn to Green when fully charged.



Short touch ON 20%-50%-100% OFF
Long touch for stepless dimming 10%-100%