

**Package contents (parts are not to scale):**

A



B



| Part | Description                   | Quantity |
|------|-------------------------------|----------|
| A    | Makeup bag with mirror inside | 1        |
| B    | USB-Type-C cable(80cm)        | 1        |


**Care and Cleaning**

**EXTERIOR MAINTENANCE**

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

**MAKEUP CASE WITH MIRROR**

Art Nr. 11000000544



## Pre-Installation

### PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

### TOOLS REQUIRED



Knife

## Product detail information:

Max Watt: LED 3W

Kelvin: 3000-4500-6500K

Lumen: 23Lumen

Battery type: 1000mAh

Charging time: 2-3 hours



Running time: 1-3 hours

Lamp gurantee: 180 day


With USB-Type C cable supplied(5V 1A)

## Switch instruction:

Please charge the mirror before use. The indicator light is Red when charging, and turns off when fully charged.




Detachable makeup mirror




Surrounded Lighting

Light touch switch



USB Type-C port



Touch to turn on the lights

Short touch to switch lights  
(white/warm/natural light)

Long touch for stepless dimming

Touch again to turn off