


Package contents (parts are not to scale):

A



B



Part	Description	Quantity
A	The fixture with wire	1
B	Type-C cable	1


Care and Cleaning

EXTERIOR MAINTENANCE

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

INTERIOR TABLE LAMP

Art Nr. 21027-022-49



Pre-Installation

PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED



Knife

Product detail information:

Input: DC 5V 2A

Switch: Touch ON/OFF

3 CCT 5000K-2700K-3500K, Brightness dimmable

Luminaire wattage : 8W, Luminaire luminous flux: 600lm

Battery type: 2×2500mAh 18650 Li-ion battery

Charging time: 4 hours

Running time: 4-6 hours

Dimmer: Touch stepless dimmable 5%-100%

Safety: Class III

Lamp guarantee: 2 year

(with 500times recharging, it means after 500times it could not be "100% full filled" but still could be recharged)

Switch instruction:

1. Please use the bottom charging port to charge before use. The indicator is red when charging.

Indicator light will be off when full charged.

2. To adjust the brightness, please touch the on/off button at the bottom, and long press the on/key to adjust the brightness from high to low. Reach the required brightness for release.

3. Short press on/key to adjust the color temperature (5000K-2700K-3500K)

