



Package contents (parts are not to scale):

A



B



Part	Description	Quantity
A	Light fixture	1
B	Type-C cable	1


Care and Cleaning

EXTERIOR MAINTENANCE

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

INTERIOR TABLE LAMP

Art Nr. 21037-014-49,21037-014-69



Pre-Installation

PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED



Knife

Product detail information:

Input: DC 5V 1A

Switch: Touch ON/OFF

Max watt:LED 2W

Lumen:230Lumen

Kelvin:3000K

Battery type: 2×1800mAh

Charging time: 6 hours

Approx 22 hrs for lowest lumen;

Approx 9 hrs for Medium lumen;

Approx 5 hrs for for highets lumen;

Safety: Class III

Guarantee: 1 year

(with 500times recharging, it means after 500times it could not be "100% full filled" but still could be recharged)

Switch instruction:

1. Please use the bottom charging port to charge before use. The indicator is red when charging.

Indicator light will be off when full charged.

2. Touch dim (short touch Low light - Medium light - High light - OFF).

