


Package contents (parts are not to scale):

A



Part	Description	Quantity
A	Lighting fixture with wire	1

Light source

230V E27 1 x 40W Max (not include)
Recommend LED bulb


Care and Cleaning

EXTERIOR MAINTENANCE

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

INTERIOR BORD LAMP

Art Nr. 23426-032-44



Pre-Installation


PLANNING THE INSTALLATION

Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED




Installation




230V E27 40W Max;
Recommend LED bulb

Installation (continued)



230V E27 40W Max;
Recommend LED bulb



Operation

- ☐ Turn on power at the circuit breaker or fuse box.
- ☐ Turn the light switch on to activate the fixture.