
Package contents (parts are not to scale):



Part	Description	Quantity
Α	Fixture body	1
В	Wall expansion particle(Φ8*L37mm)	2
С	Cross pan head self-tapping screw (M4*L32mm)	2
D	LED adaptor plug	1

Light source

Max. LED 9W 440Lumen 3000K (Dimmable)

(Lamp gurantee: 3 years, LED lifetime: 30000 hours)

Care and Cleaning

EXTERIOR MAINTENANCE

- 1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
- 2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.




INSTRUCTIONS MANUAL

for BALLONG

INTERIOR WALL LAMP

Art Nr. 26113-029-49,26113-029-00




www.lampehuset.no

Pre-Installation

PLANNING THE INSTALLATION


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

TOOLS REQUIRED




Installation

Step 1.





Step 2.



Installation (continued)

Mounting bracket size (Unit millimeter)





Operation

- ☐ Turn on power at the circuit breaker or fuse box.
- Turn the light switch on to activate the fixture.