


READ Battery lamp 5705639736775



Don't bend the gooseneck excessively to avoid damage.
Bøj ikke flexarmen for kraftigt, for at undgå, at den beskadiges



Samle anvisning

1: Fjern plastik pakningerne fra rørerne

2: Saml først **6** og tag det overskydende kabel ind i røret, skru herefter rørene sammen

3: Saml derefter **7** og gør som i pkt 2

Lampen tændes ved at trykke på lampehusets icon og dæmpes ved at trykke kortvarigt

nede **3**

Farvetemperaturen justeres ved at trykke kortvarigt på **3**

**Denne lampe er til indendørs brug, men kan bruges udenfor i "battery mode".
Produktet er ikke vandtæt eller egnet til brug i fugtige omgivelser.**

*** Battery mode : Uden 230V adaptor**

Instruction manual

1: Take off the protection plug of the tubes

2: Assembly **6** and put the spare cable into the tube, rotate the tubes to connect

3: Assembly **7** and do the same as in point 2

The lamp is being switched on/ off by touching the lamp head and dimmed by

holding the button **3**

The color of the light is being adjusted by keep touching the lamp head **3**

**This lamp is for indoor use, but can be brought outside in "battery mode **".
The lamp is not waterproof or suitable for use in humid surroundings.**

*** Battery mode : Without power supply**

