
### Package contents (parts are not to scale):



| Part | Description                                  | Quantity |
|------|--|----------|
| А    | Fixture body                                 | 1        |
| В    | Wall expansion particle(Φ8*L37mm)            | 2        |
| С    | Cross pan head self-tapping screw (M4*L32mm) | 2        |
| D    | LED adaptor plug                             | 1        |
|      |  |          |
|      |  |          |
|      |  |          |

# **Light source**

Max. LED 8W 485Lumen 3000K (Dimmable)

(Lamp gurantee: 3 years, LED lifetime: 30000 hours)

# **Care and Cleaning**

#### **EXTERIOR MAINTENANCE**

- 1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
- 2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.




# **INSTRUCTIONS MANUAL**

for ARCHES

# INTERIOR WALL LAMP

Art Nr. 42017-020-53




www.lampehuset.no

### **Pre-Installation**

#### **PLANNING THE INSTALLATION**


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

#### **TOOLS REQUIRED**




### Installation

### Step 1.





### Step 2.



## **Installation (continued)**

Mounting bracket size (Unit millimeter)





# **Operation**

- ☐ Turn on power at the circuit breaker or fuse box.
- Turn the light switch on to activate the fixture.