


**Package contents (parts are not to scale):**



Part	Description	Quantity
A	Fixture body with wire	1
B	Wall expansion particle(Φ8*L35mm)	2
C	Cross pan head self-tapping screw (ST4*L42mm)	2
D	Washer	2

**Light source**

**Max. LED 8W 1100Lumen 3000K**

**(Lamp gurantee: 3 years,LED lifetime: 30000 hours)**


**Care and Cleaning**

**EXTERIOR MAINTENANCE**

1. To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

**INTERIOR WALL LAMP (IP44)**

Art Nr. 81213-041-71




## Pre-Installation

### PLANNING THE INSTALLATION


Read all instructions before assembly and installation. Before starting installation of the fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.

### TOOLS REQUIRED




## Installation

### Step 1.




### Step 2.




## Installation (continued)


Mounting bracket size (Unit millimeter)



### Step 1.



### Step 2.



## Operation

- ☐ Turn on power at the circuit breaker or fuse box.
- ☐ Turn the light switch on to activate the fixture.