


INSTRUCTIONS MANUAL

for HARE HATT


Rechargeable light

Art Nr. 26110-024-43.26110-024-53



www.lampehuset.no

Package contents (parts are not to scale):





Product detail information:

- Vendor ref: KDR-6301
- Material: ABS&PP
- Max Watt: LED 3W
- Kelvin: 3000K
- Lumen: 80Lumen
- Battery type: 1200mAh 18650 Li-ion battery
- Lamp gurantee: 1 years · Charaina time: 3 hours
- Running time: 8-10 hours
- With 1M Type C-USB cable supplied(5V 1A) • Bluetooth version: 5.0
- Bluetooth connection range: 30M
- Support stereo
- Brightness: 3 levels brightness
- Short Touch switch to adjust the brightness: NO Low medium high OFF

Switch instruction:

Instructions for use

Light Management

Switch the On/Off-key on the back to be ON, then touch the heartshaped touch button on the chest to turn on the light. There are three levels of brightness by touching.

Bluetooth Management

Switch the On/Off-key on the back to be ON, and then long press the Bluetooth button to enter Bluetooth mode, voice prompt will be heard. At this point, the speaker is in the state of waiting for pairing and connection, and only in this state can it be paired and connected to the Bluetooth source.




- 1. Find the Mobile Settings, turn on the Bluetooth switch and click scan for searching the device.
- 2, When the Mobile displays "MD708"in the list, it indicates that the phone has found the Bluetooth speaker. Click "MD708" to enter the pairina mode.
- 3, When the phone is successfully paired with the speaker, a voice prompt will appear and a link will be displayed.


PC Connection

- 1. When the PC has Bluetooth, turn on Bluetooth. If the PC does not have Bluetooth, you must install a Bluetooth driver and plug in a Bluetooth adapter to use Bluetooth function.
- 2, Right-click the Bluetooth symbol in the lower right corner of your computer desktop and select "Add Device".
- 3, The Bluetooth adapter will automatically search for the speaker and display the words "MD708".
- 4, Double-click MD708, the computer will automatically install the driver and show Install success.

Charging Instructions

- 1. Use a power adapter with a 5V output to charge.
- 2. Please turn on the power switch before charging, the red light goes on when it's charged and goes off when it's full.
- 3. There is a voice warning when the battery is too low, and the device will automatically shut down. Please connect the power supply.





NO - Low - medium - high - OFF